

Industrial Automation

IMI Norgren

PM/31000 Serviceable air bellows Single acting

- Ø 2 3/4 ... 12 inch (Ø 78 ... 330 mm)
- Frictionless operation
- No maintenance or lubrication
- Ideal for short stroke, high-force applications
- High isolation level for vibrating machines
- Very easy to install no alignment problems



Technical features

Medium:

Compressed air lubricated or unlubricated, Nitrogen, water (with glycol)

Operation:

Single acting

Operating pressure:

5,5 bar (79 psi) recommanded dynamic pressure 8 bar (116 psi) maximum

Nominal diameters:

2 3/4, 4 1/2, 6, 8, 9 1/4, 12 inches

Strokes

From 20 ... 320 mm max., depending on diameters and number of convolutions

PM/31021

PM/31022

Operating temperature:

for PM/31000 (Standard) -30 ... +50°C (-22 ... +122°F) -40 ... +70°C* (-40 ... +158°F)* IR for TPM/31000

-20 ... +70°C (-4 ... 158°F) -25 ... +90°C* (-13 ... 194°F)* ECO for EPM/31000

+50 ... +115°C (+122 ... 239°F) -20 ... +130°C* (-4 ... +266°F)*

* The number represent the maximum permissible operating temperature. It is sutibel to operated with restriction at this temperature, the air bellow may have a reduced life time!

PM/31023 PM/31041

Materials:

End plates: Aluminium Ø 2 3/4 ... 6 inch, steel chromated Ø 8, 9 1/4, 12

inch

PM/31042 PM/31043

Central ring: aluminium or steel chromated Bellow: PM/31000: fabric reinforced NR/BR, SBR-compound rubber

PM/31061

PM/31062

TPM/31000: IR EPM/31000: ECO

Technical data

Model


Cylinder Ø [inch]	2 3/4"	2 3/4"	2 3/4"	4 1/2"	4 1/2"	4 1/2"	6"	6"
Air Port	G 1/4	G 1/4	G 1/4	G 3/8	G 3/8	G 3/8	G1/2	G1/2
Nominal Ø (inch) x convolutions	2 3/4" x 1	2 3/4" x 2	2 3/4" x 3	4 1/2" * 1	4 1/2" * 2	4 1/2" * 3	6" x 1	6" x 2
Stroke [mm]	20	45	60	40	85	100	55	115
Installation height min [mm]	50	65	80	50	65	100	55	80
Recomended max working height [mm]	65	105	130	80	135	180	100	170
Installation height max [mm]	70	110	140	90	150	200	110	190
Retracting force to reach min height [N]	200	310	300	200	240	140	200	220
Force at 6 bar [N] depending from the stroke	See graph on	page 5 & 6						
Model	PM/31063	PM/31081	PM/31082	PM/31091	PM/31092	PM/31121	PM/31122	PM/31123
Model Cylinder Ø [inch]	PM/31063 6"	PM/31081 8"	PM/31082 8"	PM/31091 9 1/4"	PM/31092 9 1/4"	PM/31121 12"	PM/31122 12"	PM/31123 12"
Cylinder Ø [inch]	6"	8"	8"	9 1/4"	9 1/4"	12"	12"	12"
Cylinder Ø [inch] Air Port	6 " G1/2	8 " G3/4	8 " G3/4	9 1/4 " G3/4	9 1/4 " G 3/4	12" G 3/4	12" G 3/4	12 " G 3/4
Cylinder Ø [inch] Air Port Nominal Ø (inch) x convolutions	6 " G1/2 6" x 3	8" G3/4 8 x 1	8 " G3/4 8 x 2	9 1/4 " G3/4 9 1/4 x 1	9 1/4" G 3/4 9 1/4 * 2	12" G 3/4 12" x 1	12" G 3/4 12" x 2	12" G 3/4 12" x 3
Cylinder Ø [inch] Air Port Nominal Ø (inch) x convolutions Stroke [mm]	6" G1/2 6" x 3 190	8" G3/4 8 x 1 95	8" G3/4 8 x 2 185	9 1/4" G3/4 9 1/4 x 1 105	9 1/4" G 3/4 9 1/4 * 2 230	12" G 3/4 12" x 1 129	12" G 3/4 12" x 2 230	12" G 3/4 12" x 3 320
Cylinder Ø [inch] Air Port Nominal Ø (inch) x convolutions Stroke [mm] Installation height min [mm]	6" G1/2 6" x 3 190 100	8" G3/4 8 x 1 95 55	8" G3/4 8 x 2 185 80	91/4" G3/4 91/4×1 105 55	91/4" G 3/4 9 1/4 * 2 230 80	12" G 3/4 12" x 1 129 51	12" G 3/4 12" x 2 230 75	12" G 3/4 12" x 3 320 110
Cylinder Ø [inch] Air Port Nominal Ø (inch) x convolutions Stroke [mm] Installation height min [mm] Recomended max working height [mm]	6" G1/2 6* x 3 190 100 255	8" G3/4 8 x 1 95 55 140	8" G3/4 8 x 2 185 80 250	9 1/4" G3/4 9 1/4 x 1 105 55 150	9 1/4" G 3/4 9 1/4 * 2 230 80 295	12" G 3/4 12" x 1 129 51 151	12" G 3/4 12" x 2 230 75 265	12" G 3/4 12" x 3 320 110 395
Cylinder Ø [inch] Air Port Nominal Ø (inch) x convolutions Stroke [mm] Installation height min [mm] Recomended max working height [mm] Installation height max [mm]	6" G1/2 6* x 3 190 100 255 285	8" G3/4 8 x 1 95 55 140 150 60	8" G3/4 8 x 2 185 80 250 265	91/4" G3/4 91/4×1 105 55 150	91/4" G 3/4 9 1/4 * 2 230 80 295 310	12" G 3/4 12" x 1 129 51 151 180	12" G 3/4 12' x 2 230 75 265 305	12" G 3/4 12* x 3 320 110 395 430



Alternative air bellows

Symbol	Model	Material	Description	Dimension see page
1	PM/31000	Standard	Ø 2 3/4 12 inches (78 310 mm)	3 and 4
	TPM/31000	IR	Ø 2 3/4 12 inches (78 310 mm)	3 and 4
	EPM/31000	ECO	Ø 2 3/4 12 inches (125 310 mm)	3 and 4

Options selector



Note: Please fill in only the numbers of digits required, e.g. PM/31023



Important instructions:

Thrust

The thrust depends on the height of the bellow. When height increases - the thrust decreases.

- Before installing the air bellow, check it carefully for any damage it may have suffered from transport or improper storage.
- Do not inflate the air bellow until it has been secured properly.

Clearance:

There must be enough clearance around the air bellow.

- The full surface of the metal parts is
 - to be used to bear the forces.
- Air bellows must be equipped with lateral guides.
- Deflate the air bellows fully before removing.
- Ensure that the bellows is not constantly in contact with hydraulic oil, lubricants, solvents, metal cuttings and welding sparks.
- Should the air bellow be subjected to special media in an application, ask Norgren for further information, specifying the medium, temperature and concentration

Stops:

To avoid damage when the bellow is compressed or extended mechanical stops at both end positions have to be used.



Dimensions

PM/31021, PM/31022, PM/31023

Dimensions in mm Projection/First angle \bigcirc





- 1 Installation diameter min.
- 2 Installation height min.
- Installation height max.
- 4 Stroke
- 5 Recommended max. working height

Table 1

Nominal Ø (inch) x convolutions	Stroke (mm)	Installation height [A] min. (mm)	Recommended working height [B] max. (mm)	Installation height [C] max. (mm)	Max. torque for mounting studs (Nm)	Natural frequency [fn] at 4 bar (Hz)	Siffness at 4 bar (N/mm)	Recomended vibration height [mm]	Weight (kg)	Model
2 3/4" x 1	20	50	65	70	5	5,3	131	60	0,35	PM/31021
2 3/4" x 2	45	65	105	110	5	3,65	49,4	90	0,4	PM/31022
2 3/4" x 3	60	80	130	140	5	_	_	_	0,5	PM/31023

ø 36

ø 78

ø 80


G 1/4

X

X

M6

PM/31041, PM/31042, PM/31043





- 1 Installation diameter min.
- 2 Installation height min.
- 3 Installation height max.
- 4 Stroke
- 5 Recommended max. working height


Table 1.1

Nominal Ø (inch) x convolutions	Stroke (mm)	Installation height [A] min. (mm)	Recommended working height [B] max. (mm)	Installation height [C] max. (mm)	Max. torque for mounting studs (Nm)	Natural frequency [fn] at 4 bar (Hz)	Siffness at 4 bar (N/mm)	Recomended vibration height [mm]	Weight (kg)	Model
4 1/2" x 1	40	50	80	90	5	3,96	148	70	0,75	PM/31041
4 1/2" x 2	85	65	135	150	5	2,85	86	130	0,95	PM/31042
4 1/2" x 3	100	100	180	200	5	_	_	_	1,2	PM/31043

PM/31061, PM/31062, PM/31063







- 1 Installation diameter min.
- 2 Installation height min.
- 3 Installation height max.
- 4 Stroke
- **S** Recommended max. working height

Table 1.2

Nominal Ø (inch) x convolutions	Stroke (mm)	Installation height [A] min. (mm)	Recommended working height [B] max. (mm)	Installation height [C] max. (mm)	Max. torque for mounting studs (Nm)	Natural frequency [fn] at 4 bar (Hz)	Siffness at 4 bar (N/mm)	Recomended vibration height [mm]	Weight (kg)	Model
6" x 1	55	55	100	110	12	3,75	283	90	1,9	PM/31061
6" x 2	115	80	170	190	12	2,26	92,5	160	1,9	PM/31062
6" x 3	190	100	255	285	12	_	-	_	1,9	PM/31063




Dimensions PM/31081, to PM/31123

øΝ

Dimensions in mm Projection/First angle








- 1 Installation diameter min.
- 2 Installation height min.
- 3 Installation height max.
- 4 Stroke
- **S** Recommended max. working height

Table 1.3

Nominal Ø (inch) x convolutions	Stroke	Installation height [A] min.	Recommended working height [B] max.	Installation height [C] max.	Max. torque for mounting studs	Natural frequency [fn] at 4 bar	Siffness at 4 bar	Recomended vibration height	Ø E	Ø D	Ø F	Н	Ø N	Weight	Model
	(mm)	(mm)	(mm)	(mm)	(Nm)	(Hz)	(N/mm)	[mm]						(kg)	
8" x 1	95	55	140	150	12	2,54	185	140	133	225	70	_	240	1,8	PM/31081
8" x 2	185	80	250	265	12	1,93	87,63	205	133	220	70	-	240	2,3	PM/31082
9 1/4" x 1	105	55	150	160	12	2,25	200	110	155	225	89	38	275	2,3	PM/31091
9 1/4" x 2	230	80	295	310	12	1,64	95,8	220	155	225	89	38	275	3,1	PM/31092
12" x 1	129	51	151	180	25	2,3	332	140	228	343	157,5	73	360	4,3	PM/31121
12" x 2	230	75	265	305	25	1,9	190	240	228	325	157,5	73	340	4,8	PM/31122
12" x 3	320	110	395	430	25	_	_	_	228	325	157,5	73	345	5,9	PM/31123

Operation angle



- 1 Installation height min 2 Installation height max

Out of alignment

F

Е

D




Table 2

Nominal Ø (inch) x convolutions	Operating angel [] max.	Out of algignment [Z] max. (mm)	Installation height [A] min. (mm)	Installation height [C] max. (mm)	Model
2 3/4" x 1	_	_	50	70	PM/31021
2 3/4" x 2	10	10	65	110	PM/31022
2 3/4" x 3	10	10	80	140	PM/31023
4 1/2" x 1	5	5	50	90	PM/31041
4 1/2" x 2	10	10	65	150	PM/31042
4 1/2" x 3	10	10	100	200	PM/31043
6" x 1	10	10	55	110	PM/31061
6" x 2	10	10	80	190	PM/31062
6" x 3	10	10	100	285	PM/31063
8" x 1	10	10	55	150	PM/31081
8" x 2	10	10	80	265	PM/31082
9 1/4" x 1	10	10	55	160	PM/31091
9 1/4" x 2	10	10	80	310	PM/31092
12" x 1	10 20	10	51	180	PM/31121
12" x 2	15 25	20	75	305	PM/31122
12" x 3	15 30	30	110	430	PM/31123


Operation angle


Tilt angles from $5 \dots 30^{\circ}$ are possible, depending on the air bellow

design.
Ensure application is within minimum and maximum installation heights.



Thrust (at 2, 4, 6, 8 bar), volume (at 6 bar)






⁻ Thrust (N) - - Volume (I)


Caution!


Ensure that all applications are within the max. installation height. For applications in the grey area please contact Norgren technical service.




Thrust (at 2, 4, 6, 8 bar), volume (at 6 bar)











PM/311121


Stroke (mm)







PM/31123



Caution!

Ensure that all applications are within the max. installation height. For applications in the grey area please contact Norgren technical service.

⁻ Thrust (N) - - Volume (l)



Application example - Air bellow as an actuator

A 1000 kg conveyor carrying a 550 kg pallet needs to be lifted by 90 mm (stroke) in order to transfer the pallet to another level. Four (4) air bellows should be used. The available operating pressure is 5 bar.

The operating temperature is 50°C. There is a 270 mm square space to house each air bellow. Compression and extension stops are provided. The air bellows have to be mounted between in a space which are 85 mm apart. During the lifting operation the conveyor may tilt in the second half of the stroke by a max. of 9°.

Step 1: Fill in and complete the datasheet

a)	Total weight to be lifted:	F	=	(1000 kg + 550 kg) x 10 m/s2 = 15500 N
b)	Number of air bellows:	n	=	4
c)	Thrust per air bellow:	f	=_	15500 N = 3875 N 4
d)	Operating pressure:	Р	=	5 bar
e)	Required stroke:	S	=	90 mm
f)	Vertical space:	Χv	=	85 mm
g)	Horzontal space:	Xh	=	270 mm
h)	Operating temperature:	Τ	=	50°C
i)	Operation angle:	а	=	9°
j)	Out of alignment:	Α	=	0 mm
k)	Chemical resistance:			normal environment

Step 2:

From table 1.1 ... 1.3 air bellows have to be selected, that have a stroke of 90 mm and clearance around the air bellows smaller than Xh = 270 mm. We select: PM/31043, PM/31062, PM/31063, PM/31081 and PM/31082

Step 3:

Calculate the total height at which the air bellow should be used,

Vertical space Xv 85 mm Stroke S 90 mm

175 mm Total height

By refering to the total height of 175 mm and the vertical space of

85 mm

PM/31062 Installation height [A] min = 80 mm


Installation height (C) max = 190 mm and


PM/31082 Installation height [A] min = 80 mm Installation height (C) max = 265 mm

can be used from table 1.2 & 1.3

Step 4:

Check the thrust at 5 bar at a height of 175 mm. From the charts in the datasheet 5 & 6 we can see that:





PM/31062 will provide 4800 N at 6 bar. To get the figure for 5 bar, we have to calculate:

 $4800 \text{ N} \times 5 = 4000 \text{ N} \text{ at 5 bar}$ 6

PM/31082 will provide 11500 N at 6 bar. To get the figure for 5 bar, we have to calculate:

11000 N x 5 = 9166 N at 5 bar 6

Result:

Both air bellows can provide the required thrust of 3875 N. But the PM/31062 is still working on the critical zone and force can drop done via pressure issue.

Please select the bigger one PM/31082.

Step 5:

Check the operation angel and the out of alignment when the selected air bellow can tilt, see table 2.

i) max. operation angle 10° is higher as existing operating angel 9°. j) max. out of alignment is 10 mm is higher as existing alignment 0 mm.

Result:

PM/31082 can be used

Step 6:

Check all remaining parameters h) At 50°C Standard rubber material -30 ... + 50°C k) No special chemical resistance is required

Result:

PM/31082 is the chosen air bellow, because it meets all requirements.



Application example - Air bellow as a vibration isolator

A hydraulic power unit with an excitation frequency (fe) between 1200 and 3000 cycles/min. (= 20 to 50 Hz) must be vibration isolated. The total weight of the power unit is 3000 kg. The supporting area under the unit is 1,2 m x 0,8 m. The operating temperature is 50°C. The space for the installation is 220 mm high. Four air bellows will be used. The max. operating pressure is 4 bar. A minimum of 97% vibration isolation has to be reached.

Step 1: Fill in and complete the datasheet

a)	Total weight to be isolated:	F	=	3000 kg x 10 m/s2 = 30000 N
b)	Number of air bellows:	n	=	4
c)	Thrust per air bellow:	f	=	30000 N = 7500 N
d)	Operating pressure:	Р	=	4 bar
f)	Vertical space:	Χv	=	240 mm
g)	Horizontal space:	Xh	=	400 mm (0,8 m /2)
h)	Operating temperature:	Т	=	50°C
k)	Chemical resistance:			normal environment
m)	Minimum isolation rate:	-	=	97%
p)	Excitation frequency	fe	=	min. 20 Hz, max. 50 Hz

Two types of air bellows are chosen. Each one has to work with a vibration height lower than 240 mm and fit in a horizontal space samler than 400 mm. From table 1 we select:

1. PM/31092 - Vibration height = 220 mm - Clearance around the air bellow = 275 mm - Airspring natural frequency "fn" at 4 bar = 1,64 Hz - Stiffness at 4 bar = 95,8 N/mm 2. PM/31122 - Vibration height = 220 mm - Clearance around the air

2. PM/31122 - Vibration height = 220 mm - Clearance around the air bellow = 340 mm- Airspring natural frequency "fn" at 4 bar = 1,9 Hz - Stiffness at 4 bar 190 N/mm

Step 2:

Take the air bellow with the lowest airspring natural frequency fn = 1,64 Hz and the lowest stiffness at 95,8 N/mm in order to get the highest isolation rate refering to fe min. = 20 Hz. Air bellow PM/31092 is chosen.

Step 3:

Calculate the isolation rate (I) of the PM/31092 by using the formula:

Formula:

$$I = 1 - \frac{1}{\frac{\text{fe}}{\text{fn}} 2} - 1$$


Example:

$$I = 1 - \frac{1}{(20)^{2} - 1}$$

Step 4:

Check the thrust at 4 bar at a height of 220 mm. From the charts in the datasheet page 6 we can see that.






Step 5:

Check all remaining parameters h) At 50°C Standard rubber material (-50); -5 20°C) can be used. g) No special chemical establishment of 220 mm at 4 bar.

Result

4 x PM/31092 air bellows are chosen. They will provide 99,3% vibration isolation and lift the 3000 kg weight at 4 bar.



fe = Excitation frequency of load fn = Airspring natural frequency



Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under »Technical features/data«.

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult Norgren.

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes.

The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.